

# Mechanisms

## Seating Mechanisms (Manual, Gas Lift and Synchro)

All of our mechanisms come standard in a Black finish.

### Manual Control

---



#### MC1

Available on Models:

- 1. Tension Knob** – Turn clockwise to increase tension, counterclockwise to decrease tension.
- 2. Manual Height Adjustment** – Hold bell and turn chair clockwise to lower, counter clockwise to raise.

### Gas Lift Control

---



#### GL2

Available on Models: Zero7 and Millennium

- 6. Pneumatic Height Adjustment** – To lower, pull lever up while seated; to raise, pull paddle up with your weight off the seat.

### Synchro Control

---




#### PMB

Available on Models: Zero7 and Link

- 1. Tension Knob** – Turn clockwise to increase tension, counterclockwise to decrease tension.
- 6. Pneumatic Height Adjustment** – To lower, pull lever up while seated; to raise, pull paddle up with your weight off the seat.
- 9. Seat Angle/Tilt Lock Adjustment** – To change seat angle, pull paddle up while seated, push paddle down to lock when desired angle is achieved.

### Tilt Control

---



#### TC1

Available on Models: Jendra

- 4. Back Angle Adjustment** – While seated pull paddle up, when desired angle achieved, push paddle down to lock.
- 6. Pneumatic Height Adjustment** – To lower, pull lever up while seated; to raise, pull paddle up with your weight off the seat.
- 8. Back Height Adjustment** – Turn clockwise to loosen, move chair back to desired height and re-tighten.
- 11. Infinite Seat Angle Adjustment** – Push paddle down to lock chair in position; to allow continuous movement, pull paddle down.


# Mechanisms

## Seating Mechanisms (Knee Tilt and Multi-Tilt)

All of our mechanisms come standard in a Black finish.

### Knee Tilt Controls

---



#### KT1 and KT5

Available on Models: Jendra 3604, Jendra 3614 and Millennium (KT5)

- 1. Tension Knob** – Turn clockwise to increase tension, counterclockwise to decrease tension.
- 5. Tilt Lock** – To lock chair in position, push paddle down; to allow free tilt movement, pull paddle up.
- 6. Pneumatic Height Adjustment** – To lower, pull lever up while seated; to raise, pull paddle up with your weight off the seat.

---

#### START105


Available on Models: Rete

- 1. Tension Knob** – Turn clockwise to increase tension, counter clockwise to decrease tension.
- 12. Multi-Function Control Arm** – Single lever actions the gas spindle and locks in 5 positions with “shock-resistance.” Slide lever forward to lock tilt. Slide lever backward to unlock tilt.

---

### Multi-Tilt Control

---



#### MT1

Available on Models: Jendra 3604 and Jendra 3614

- 1. Tension Knob** – Turn clockwise to increase tension, counterclockwise to decrease tension.
- 4. Back Angle Adjustment** – While seated pull paddle up, when desired angle achieved, push paddle down to lock.
- 6. Pneumatic Height Adjustment** – To lower, pull lever up while seated; to raise, pull paddle up with your weight off the seat.
- 7. Forward Tilt** – Lean back in chair, bring tilt lock paddle to the up position and rotate lever clockwise to allow the seat to angle forward; to lock in position depress tilt lock paddle into the locked position.
- 8. Back Height Adjustment** – Turn clockwise to loosen, slide chair back to desired height and re-tighten.
- 9. Seat Angle/Tilt Lock Adjustment** – To change seat angle, pull paddle up while seated, push paddle down to lock when desired angle is achieved.